



Refrigeration Hardware

# W94 Door Closer Template and Installation Instructions

## INSTRUCTIONS:

- 1- DRAW VERTICAL CENTERLINE ON DOOR AND ON FRAME
- 2- SPOT AND DRILL  $5/32$ " HOLES AT CROSS LINES IN 4 LOCATIONS MARKED "A"
- 3- ASSEMBLE ALL PARTS AND CHECK FOR PROPER OPERATION
- 4- ADJUST AS REQUIRED BY LOOSENING SCREWS & SLIDING MEMBERS IN ELONGATED HOLES TO OBTAIN ADJUSTMENT
- 5- AFTER OBTAINING SATISFACTORY ADJUSTMENT, TIGHTEN SCREWS & INSTALL 5 MORE SCREWS IN THE HOLES MARKED "B"

NOTE: Mounting holes sized for #10 screw

